

How to make coffee


Equipment required:

- Bean (Bean container)
- Water (Water Tank)
- Milk tube (connecting machine & milk container)

These short instructions do not replace the »J6 Instructions for Use«. Make sure you read and observe the safety information and warnings first in order to avoid hazards.

»Display«

Place Cup under the coffee spout



Select Coffee by pressing Rotary Switch / Start Menu



Permanent Personalize Coffee Setting



Press P Button » Product Setting - Expert Mode«

» Enough Coffee? « - Adjust volume by Rotary Switch

» Coffee Strength « - Adjust coffee grind amount by Rotary Switch



Alternative:

1. Hold Drink Button for 2-3 sec in start menu
2. » Enough Coffee? «
3. » Save«